


KARCHER AUTOMATIC SCRUBBER



KARCHER AUTOMATIC SCRUBBER

Before Use ("b"):

1. Review safety procedures.*
2. Inspect hoses, squeegees and other parts for damage.
3. If using a pad, install the pad on the pad holder.
4. Install the pad holder.
5. Fill the solution tank with cleaning solution
6. Connect the batteries to the machine, press the memo button once and start cleaning.

After Use ("a"):

1. While moving, press the Memo button to automatically raise, retract, and stop all the machine systems.
2. Empty the recovery tank and rinse clean.
3. Remove the brushes or pad holders, rinse, and hang to dry.
4. Remove the squeegee, rinse with warm water, and reinstall.
5. Drain and rinse solution tank if machine is going to sit for an extended period.
6. Attach battery charger and turn on.

* Task Card



ECOLAB
Professional Products Division

A&G Supply Ltd.

Perform Once Weekly:

* Task Card

1. Review safety procedures.*
2. Remove the vent caps.
3. Check the water level in each battery cell.
4. Use distilled water to fill each cell to the bottom of the filler tube. Do not overfill.
5. Tighten the vent caps.
6. Wash the tops of the batteries with a solution of baking soda and water (2 tablespoons of baking soda to 1 litre of water).

ECOLAB
Professional Products Division

A&G Supply Ltd.